

Borate Indicator Test Solution

TO BE USED FOR DETERMINING BORATE
TREATMENTS TO WOOD

KEEP AWAY FROM CHILDREN

STORE IN A COOL, DRY PLACE
KEEP IN THE ENCLOSED CONTAINER



100 Nisus Drive • Rockford, TN 37853
(800) 264-0870

Refer to SDS for safety information

FIRST AID:

IF IN EYES OR ON SKIN: Flush with water for 15 minutes. Seek medical attention if irritation develops or persists.

IF SWALLOWED: Clean mouth with water and drink plenty of water.

DIRECTIONS FOR USE:

This test is used only to show the presence of borate on wood to determine if a borate wood treatment has been applied. More advanced test procedures are required if specific levels of borate retention are needed.

Borate Indicator Test Solution should be spray applied to a small area on unsealed, clean, dry wood surface to indicate the presence of borate. Spray to wetness, but not to run off. Allow solution to dry for 3-5 minutes. Monitor color development. Any maroon or burgundy color indicates the presence of borate.

NOTE: The Borate Indicator Test Solution will dry to a long lasting purple stain. Do not apply the solution to wood or other surface areas where this stain could be considered unsightly.