

# CONTRACTOR'S RFP

## Contractor's Request for Proposal for Subterranean Termite Prevention to New Structures *Bora-Care® termiticide applications only.*

Contractor Name \_\_\_\_\_

Company \_\_\_\_\_

City/State/ZIP \_\_\_\_\_

Phone/E-Mail \_\_\_\_\_

### Applications will be made according to the product's EPA label directions to include:

- Compliance with state and local laws
- Graph and documentation of application
- Spray optional pattern colorant to show applications except in areas that may be exposed after building enclosure (*PMP should consult spray pattern colorant memo.*)

### MINIMUM LABEL APPLICATION REQUIREMENTS:

- Bora-Care must be mixed at a one (1) part water to (1) part Bora-Care solution (23%) per label instructions.

### FOR SLAB FOUNDATIONS YOU WILL:

- Apply a protective coat to sill/base plates and 24" up on studs and other wood members in contact with the slab foundation. Apply second coat to sill plate.
- Spray concrete 2" to 8" horizontally out from sill or base plate.
- Treat all pipe protrusions within stud walls or free standing 24" up from slab surface and extending horizontally 6" out on the slab surface.
- Apply product into bath trap area and extend application at least 1' out onto slab surface.
- Vertically apply product to both sides of exterior sheathing to point of wetness. If one side is inaccessible, apply two coats to one side.
- Treat expansion joints according to product registered label.

### FOR CRAWL SPACE FOUNDATIONS YOU WILL:

- Apply to all wood in a 24" area in from exterior wall foundations to include sill plate, header joist, floor joists and sub-floor. Apply second coat on sill plate and header joist.
- Apply to all wood in contact with foundation piers out 24" from contact with foundation pier.
- Apply to interior surface of all foundation walls and piers extending 24" up from soil contact.
- Apply to structural wood on the exterior walls to extend 12" above contact with the top of the header joist to include the edge of the sub-floor, sill above sub-floor, stud wall and exterior sheathing.

### FOR BASEMENT FOUNDATIONS YOU WILL:

- Apply to all wood in a 24" area in from exterior wall foundations to include sill plate, header joist, floor joists and sub floor. Apply second coat on sill plate and header joist.
- Apply to structural wood on the exterior walls to extend 12" above contact with the top of the header joist to include the edge of the sub-floor, sill above sub-floor, stud wall and exterior sheathing.
- Apply to interior surface of all foundation walls extending 24" up from concrete slab.
- Apply product into bath trap area and extend at least 1' out on slab surface.

### FOR FINISHED BASEMENTS:

- For all frame walls in contact with foundation vertically apply to all wood including sill plate, total stud boards and all the top plate (or runner). Spray slab 2"-8" horizontally out from sill or base plate.
- For all interior framed walls apply to sill/base plate and 24" up on studs and other wood members in contact with slab foundation. Apply second coat on sill. Spray concrete slab 2"-8" horizontally out from sill or base plate.
- Treat all pipe protrusions within stud walls or free standing in slab 24" up from slab and extend horizontally 6" out on the slab surface.

### APPLICATION TO ANY OTHER AREAS REQUIRED BY THE BORA-CARE REGISTERED LABEL

BID PRICE: Per Unit \_\_\_\_\_ Per Square Foot \_\_\_\_\_  Use spray colorant  Do not use spray colorant  
Model(s) \_\_\_\_\_ Price per Unit \_\_\_\_\_ Model(s) \_\_\_\_\_ Price per Unit \_\_\_\_\_

Pest Management Company Name \_\_\_\_\_

City/State/Zip \_\_\_\_\_

Contact Name \_\_\_\_\_ Contact Phone \_\_\_\_\_

*All applications will be in compliance with the EPA Registered Label, federal and state laws and requirements listed above.*

Pest Management Company Representative:

Contractor Company Representative:

Signature \_\_\_\_\_ Signature \_\_\_\_\_

Name \_\_\_\_\_ Name \_\_\_\_\_

Title \_\_\_\_\_ Title \_\_\_\_\_

Date \_\_\_\_\_ Date \_\_\_\_\_