

# BORA-CARE NEW CONSTRUCTION APPLICATION WORKSHEET (FIELD USE)

(2 ft. Barrier Treatment) *Always read, understand and follow the label and regulations.*

## **SLAB AREAS**

**LINEAR FEET OF ALL EXTERIOR WOOD STUD WALLS** ..... \_\_\_\_\_  
 (To treat sills, slab & 24" vertical band)

**LINEAR FEET OF ALL INTERIOR WOOD STUD WALLS** ..... **+** \_\_\_\_\_  
 (To treat sills, slab & 24" vertical band)

*Note: Plumbing penetrations included in calculations.* (Total linear feet of stud walls)

= \_\_\_\_\_  
 $\div 200 =$  **A.** \_\_\_\_\_

**NUMBER OF BATH TRAPS** ..... \_\_\_\_\_  
 (16 oz./sq. ft.)

$\times 0.125 =$  **B.** \_\_\_\_\_

**LINEAR FEET OF ALL EXTERIOR SIDING WALLS** ..... \_\_\_\_\_  
 (To treat exterior plywood or OSB siding 24" vertical band; amounts same for treating both sides once or on one side twice.)

$\times 2 =$  \_\_\_\_\_

$\div 400 =$  **C.** \_\_\_\_\_

(Square feet of siding)

**TOTAL GALLONS OF BORA-CARE 1:1 DILUTED SOLUTION NEEDED** ..... **A+B+C =**

**TOTAL GALLONS OF BORA-CARE CONCENTRATE NEEDED:** **DILUTED SOLUTION  $\div 2 =$**

## **CRAWLSPACE OR BASEMENT AREA**

**LINEAR FEET OF SILL PLATES ON FOUNDATION (wood)** ..... \_\_\_\_\_  
 (To treat foundation sill plate, header, floor joists & subfloor as a 24" horizontal band.)

**LINEAR FEET OF WOOD ELEMENTS AROUND PIERS** (number of piers: \_\_\_\_\_ x 8) ..... **+** \_\_\_\_\_  
 (To all wood in contact with pier in a 24" horizontal band.)

= \_\_\_\_\_  
 (Total linear feet)

$\div 100 =$  **A.** \_\_\_\_\_

**LINEAR FEET OF EXTERIOR WOOD STUD WALLS** ..... \_\_\_\_\_  
 (To treat exterior walls, sills, studs & sheathing 12" above box header & sills to satisfy 2' rule)

$\div 160 =$  **B.** \_\_\_\_\_

**LINEAR FEET OF ALL CRAWLSPACE/BASEMENT CONCRETE WALLS (wood)** ..... \_\_\_\_\_  
 (Measure linear feet around support piers and foundation. Treat 24" vertical band.)

$\times 2 =$  \_\_\_\_\_

(Square feet)

$\div 400 =$  **C.** \_\_\_\_\_

**LINEAR FEET OF ALL INTERIOR STUD WALLS (finished basement)** ..... \_\_\_\_\_  
 (To treat sills, slab & 24" vertical band.)

*Note: Plumbing penetrations included in calculations.*

$\div 200 =$  **D.** \_\_\_\_\_

**LINEAR FEET OF STUD WALLS AGAINST FOUNDATION (finished basement)** ..... \_\_\_\_\_  
 (Within 3" of foundation, to treat entire stud, slab, sill plate on slab & top plate)

$\div 50 =$  **E.** \_\_\_\_\_

**NUMBER OF BASEMENT TRAPS** ..... \_\_\_\_\_  
 (16 oz./sq. ft.)

$\times 0.125 =$  **F.** \_\_\_\_\_

**TOTAL GALLONS OF BORA-CARE 1:1 DILUTED SOLUTION NEEDED** ..... **A+B+C+D+E+F =**

**TOTAL GALLONS OF BORA-CARE CONCENTRATE NEEDED:** **DILUTED SOLUTION  $\div 2 =$**