

# BORA-CARE WORKSHEET: PREVENTATIVE AND REMEDIAL BORA-CARE TREATMENTS FOR ATTICS

|                                       |   |  |
|---------------------------------------|---|--|
| <b>Total Board Feet to Be Treated</b> | <p>• <b>Determine Total Board Feet (of lumber to be treated)</b><br/>NOTE: Full attic treatments include insulation on attic floor: multiply square footage of attic by factor below based on attic peak height to get average Total Board Feet.</p> <p><b>Use A <u>or</u> B to determine Total Board Feet:</b></p> <p>A. Attic peak is 6 feet high or less ..... <b>Attic Sq. Ft. x 2</b></p> <p style="text-align: right;">= _____</p> <p>B. Attic peak is higher than 6 feet ..... <b>Attic Sq. Ft. x 2.5</b></p> <p style="text-align: right;">= _____</p> <p>NOTE: If floor is <b>not</b> insulated, multiple <i>Total Board Feet</i> (above) by 1.2 to include treatment of attic floor rafters (<i>if floor is insulated, leave blank</i>) . . .x <b>1.2</b></p> <p style="text-align: right;">x _____</p>                   |  |
|                                       | <p>• <b>Total Board Feet to Be Treated</b></p> <p style="text-align: right;">= _____</p> <p style="text-align: center;">Total Board Feet to Be Treated</p>  |  |
| <b>Solution Needed</b>                | <p>• <b>Determine Total Gallons of BORA-CARE <u>Solution</u> needed to treat attic</b></p> <p>Divide <i>Total Board Feet to Be Treated</i> (from row 3 above) by 400. . . . . ÷ <b>400</b></p> <p>(One gallon of BORA-CARE solution treats 400 board feet.)</p> <p style="text-align: right;">= _____</p> <p style="text-align: center;">Total Gallons of BORA-CARE Solution</p>  |  |
| <b>Concentrate Needed</b>             | <p>• <b>Determine Total Gallons of BORA-CARE <u>Concentrate</u> needed to treat attic</b></p> <p><b>Use A <u>or</u> B to determine gallons of BORA-CARE <u>Concentrate</u> needed:</b></p> <p>A. <i>Preventative Treatments (5:1 solution)</i>: Divide <i>Total Gallons of BORA-CARE Solution</i> (above) by 6 to get gallons of concentrate required. . . . . ÷ <b>6</b></p> <p>(5 gal. water + 1 gal. BORA-CARE = 6 total units of 5:1 solution)</p> <p>B. <i>Remedial Treatments (1:1 solution)</i>: Divide <i>Total Gallons of BORA-CARE Solution</i> (above) by 2 to get gallons of concentrate required. . . . . ÷ <b>2</b></p> <p>(1 gal. water + 1 gal. BORA-CARE = 2 total units of 1:1 solution).</p> <p style="text-align: right;">= _____</p> <p style="text-align: center;">Total Gallons of BORA-CARE Concentrate</p> |  |

**Example Preventative Attic Treatment:**

**A 1,000 square foot attic that is 6 feet high with insulation on floor**

- 1,000 X 2 = 2,000 average board feet
- 2,000 ÷ 400 = 5 gallons of solution required
- 5 gallons ÷ 6 = .83 gallons of concentrate required

